

# E124



**FAAC**



## E124 control unit – rapid guide

### WARNINGS

- Important! For the safety of people, it is important that all the instructions be carefully observed.
- Incorrect installation or incorrect use of the product could cause serious harm to people.
- Carefully read the instructions before beginning to install the product and keep them for future reference.
- The symbol  indicates notes that are important for the safety of persons and for the good condition of the automated system.
- The symbol  draws your attention to the notes on the characteristics and operation of the product.
- Before attempting any work on the control unit (connections, maintenance), always turn off power.
- Install, upstream of the system, a differential thermal breaker with adequate tripping threshold,
- Connect the earth cable to the relevant terminal.
- Always separate power cables from control and safety cables (push-button, receiver, photocells, etc.). To avoid any electrical disturbance, use separate sheaths or a screened cable (with the screen earthed).

### CE DECLARATION OF CONFORMITY

**Manufacturer:** FAAC S.p.A.  
**Address:** Via Calari, 10 - 40069 Zola Predosa BOLOGNA - ITALY  
**Declares that:** The E124 control unit

- conforms to the essential safety requirements of the following EEC directives

2006/95/EC Low Voltage Directive  
 2004/108/EC Electromagnetic Compatibility Directive

Additional note:

This product underwent tests in a typical uniform configuration  
 (all products manufactured by FAAC S.p.A.).

Bologna, 01 March 2014

The Managing Director  
 A.Marcellan



### TECHNICAL SPECIFICATIONS

|  |  |
|--|--|
| <b>Primary power feed from mains</b>   | with switching power feed<br>230/115 V~ - 50/60 Hz   |
| <b>Secondary power feed</b>            | 24 Vdc - 16 A max.<br>(min. 20 Vdc. - max. 28 Vdc.)  |
| <b>Power absorbed from mains</b>       | stand-by = 4W<br>max. ~ 400 W  |
| <b>Max. load for motor</b>             | 7 A  |
| <b>Power feed for accessories</b>      | 24 Vdc   |
| <b>Accessories max. current</b>        | 24Vdc max. 500 mA<br>BUS-2EASY max. 500 mA   |
| <b>Battery charge current</b>          | 180 mA   |
| <b>Operating ambient temperature</b>   | (-20 - +55) °C   |
| <b>Protective fuses for unit</b>       | All self resetting   |
| <b>Protective fuses for power pack</b> | 2.5 A  |
| <b>Function logics</b>                 | Semiautomatic, Automatic,<br>"step-by-step" Semiautomatic, Automatic<br>with reverse during pause, Automatic<br>step-by-step, Safety devices automatic,<br>Safety devices step-by-step automatic,<br>"b" Semiautomatic, mixed logic "bC",<br>Dead-man, Automatic with timer function |
| <b>Work time</b>                       | Programmable (from 0 to 9 min 50 sec)  |
| <b>Pause time</b>                      | Programmable (from 0 to 9 min 50 sec)  |

|                               |  |
|-------------------------------|--|
| <b>Motor power</b>            | Programmable on 50 levels  |
| <b>Motor speed</b>            | Programmable on 10 levels  |
| <b>Connector inputs</b>       | Switching feeder, Battery,<br>Decoder/Minidec/RP, X-COM, module<br>XF433/868, USB                  |
| <b>Terminal board inputs</b>  | BUS-2EASY, Inputs from IN1 to IN5,<br>Travel limit device, Encoder.                                |
| <b>Terminal board outputs</b> | Flashing lamp, Motors, Electrical lock,<br>OUT1, OUT2 (programmable), power<br>feed to accessories |
| <b>Programming</b>            | 1st and 2nd lev. with 3 keys (+, -, F) and<br>LCD display.<br>3rd lev. with PC connected via USB   |




*These instructions are to be considered as a rapid guide for installation. The complete instructions can be downloaded at the following address: [www.faacgroup.it](http://www.faacgroup.it)*



*To access PROGRAMMING FROM PC, connect the USB cable to the dedicated connector and consult the relative instructions.*

LAYOUT AND COMPONENTS OF E124 BOARD




DESCRIPTION OF COMPONENTS

|      |   |
|------|---|
| LCD  | SIGNALS AND PROGRAMMING DISPLAY             |
| SW1  | "R1" PROGRAMMING PUSH-BUTTON                |
| SW2  | "R2" PROGRAMMING PUSH-BUTTON                |
| SW3  | "SETUP" PUSH-BUTTON                         |
| SW4  | "+" PROGRAMMING PUSH-BUTTON                 |
| SW5  | "-" PROGRAMMING PUSH-BUTTON                 |
| SW6  | "F" PROGRAMMING PUSH-BUTTON                 |
| SW7  | "RESET SW" SOFTWARE RESET PUSH-BUTTON       |
| DL1  | INPUT STATUS CONTROL LED "IN1"              |
| DL2  | INPUT STATUS CONTROL LED "IN2"              |
| DL3  | INPUT STATUS CONTROL LED "IN3"              |
| DL4  | INPUT STATUS CONTROL LED "IN4"              |
| DL5  | INPUT STATUS CONTROL LED "IN5"              |
| DL6  | INPUT STATUS CONTROL LED "FCA1"             |
| DL7  | INPUT STATUS CONTROL LED "FCC1"             |
| DL8  | INPUT STATUS CONTROL LED "FCA2"             |
| DL9  | INPUT STATUS CONTROL LED "FCC2"             |
| DL10 | INPUT STATUS CONTROL LED "ENC1" (Gatecoder) |
| DL11 | INPUT STATUS CONTROL LED "ENC2" (Gatecoder) |
| DL12 | LED FOR DEVICE BUS-2EASY ACTIVE             |
| DL13 | LED FOR BUS 2-EASY DIAGNOSTICS              |
| DL14 | LED SIGNALLING PRIMARY POWER ON             |
| DL15 | LED SIGNALLING SECONDARY POWER ON           |

|      |   |
|------|---|
| DL16 | LED FOR "SW1" PUSH-BUTTON (R1 PUSH-BUTTON)      |
| DL17 | LED FOR "SW2" PUSH-BUTTON (R2 PUSH-BUTTON)      |
| DL18 | LED FOR "SW3" PUSH-BUTTON (SETUP PUSH-BUTTON)   |
| DL19 | PRESSURE SIGNALLING LED "RESET SW" PUSH-BUTTON  |
| DL20 | ALARM SIGNALLING LED "ALARM"                    |
| J1   | POWER FEEDER SWITCHING CONNECTOR                |
| J2   | SECONDARY POWER SELECTOR                        |
| J3   | CONNECTOR FOR CONNECTION TO BUS-2EASY DEVICES   |
| J4   | CONNECTOR FOR TERMINAL BOARD INPUTS             |
| J5   | CONNECTOR FOR OUT2 OUTPUT (see 2nd level prog.) |
| J6   | TRAVEL LIMITS CONNECTOR                         |
| J7   | CONNECTOR FOR LEAF 1 AND LEAF 2 ENCODER INPUTS  |
| J8   | CONNECTOR FOR OUT1 OUTPUT (see 2nd level prog.) |
| J9   | FLASHING LAMP OUTPUT CONNECTOR                  |
| J10  | CONNECTOR FOR ELECTRICAL LOCK OUTPUT            |
| J11  | LEAF 1 MOTOR CONNECTOR                          |
| J12  | LEAF 2 MOTOR CONNECTOR                          |
| J13  | CONNECTOR FOR RECEIVER MODULE XF433/XF868       |
| J14  | CONNECTOR: DECODER / MINIDEC / RP RECEIVER      |
| J15  | USB CONNECTOR FOR PROGRAMMING FROM PC           |
| M1A  | ACCESSORIES MODULE CONNECTOR                    |

**POWER FEED**



**J1:** Select the correct power feed, by turning the power switching selector to its correct position (Default 230 Vac.)



**To ensure correct operation, the switching feeder must be connected to the earth conductor in the system. Install an adequate differential thermal breaker upstream of the system.**

**SECONDARY POWER FEED**

**J2:** In the absence of a primary feed from the mains, the control unit can be fed by a secondary low voltage (24Vdc) power feed. Power can be supplied by a pack of batteries, recharged by a battery charger integrated in the board, or by a stabilised power feeder. In both cases, the power supply must have the following characteristics:

**Voltage: (24 ± 4) Vdc  
Current: 16 A max.**



**If you use an external stabilised feeder, you must disable the “battery charger” function via the PC (see dedicated instructions).**

**INPUTS DEFAULT SETTING**

**Terminal-board J4**

|     |        |              |
|-----|--------|--------------|
| IN1 | OPEN A | N.O. contact |
| IN2 | OPEN B | N.O. contact |
| IN3 | STOP   | N.C. contact |
| IN4 | FSW OP | N.C. contact |
| IN5 | FSW CL | N.C. contact |

**Connector J13 – XF Module (OMNIDEC)**

|           |        |
|-----------|--------|
| Channel 1 | OPEN A |
| Channel 2 | OPEN B |

**Connector J14 - Radio**

|               |        |
|---------------|--------|
| Channel 1 RP  | OPEN A |
| Channel 2 RP2 | OPEN B |

**TERMINAL BOARD MOTORS**

**J11 (MOT1):** Connection of motor connected to leaf 1, i.e. the leaf which opens first during an opening operation.

**J12 (MOT2):** Connection of the motor connected to leaf 2, i.e. the leaf which opens second.



**If only one motor is connected, it must be connected to terminal J11 (MOT1).**



**If, during the first movement of the SETUP procedure, the leaves open instead of closing, the motor connection cables must be changed over.**

**LED OPERATION**

| LED  | Description                                       | ON (contact closed)                   | OFF (contact open)                   |
|------|---|---------------------------------------|--------------------------------------|
| DL1  | IN1 OPEN A  | Command enabled                       | Command disabled                     |
| DL2  | IN2 OPEN B  | Command enabled                       | Command disabled                     |
| DL3  | IN3 STOP  | Command disabled                      | Command enabled                      |
| DL4  | IN4 FSW OP  | Safety devices disabled               | Safety devices tripped               |
| DL5  | IN5 - FSW CL                                      | Safety devices disabled               | Safety devices tripped               |
| DL6  | FCA1  | Opening travel-limit devices free     | Opening travel-limit devices engaged |
| DL7  | FCC1  | Closing travel-limit devices free     | Closing travel-limit devices engaged |
| DL8  | FCA2  | Opening travel-limit devices free     | Opening travel-limit devices engaged |
| DL9  | FCC2  | Closing travel-limit devices free     | Closing travel-limit devices engaged |
| DL10 | ENC1  | Flashing during operation (Gatecoder) |                                      |
| DL11 | ENC2  | Flashing during operation (Gatecoder) |                                      |
| DL12 | SIGNALLING LED FOR DEVICE <b>BUS-2EASY</b> ACTIVE |                                       |                                      |
| DL13 | SIGNALLING LED FOR <b>BUS 2-EASY</b> DIAGNOSTICS  |                                       |                                      |
| DL14 | LED SIGNALLING PRIMARY POWER ON                   |                                       |                                      |
| DL15 | LED SIGNALLING SECONDARY POWER ON                 |                                       |                                      |
| DL16 | LED FOR “SW1” PUSH-BUTTON (R1 PUSH-BUTTON)        |                                       |                                      |
| DL17 | LED FOR “SW2” PUSH-BUTTON (R2 PUSH-BUTTON)        |                                       |                                      |
| DL18 | LED FOR “SW3” PUSH-BUTTON (SETUP PUSH-BUTTON)     |                                       |                                      |
| DL19 | LED “RESET SW” PUSH-BUTTON                        |                                       |                                      |
| DL20 | ALARM SIGNALLING LED “ALARM”                      |                                       |                                      |




**Flashing LED ALARM indicates alarm in progress (a situation which does not prejudice gate operation)**



**LED ALARM on steady light indicates error in progress (a situation which blocks operation until cause of error is eliminated)**



ELECTRICAL CONNECTIONS



CONNECTION OF TRADITIONAL SAFETY DEVICES

With the E124 control unit, you can use both traditional photocells (N.C. contact with relay) and/or photocells with BUS-2EASY (open collector contact).

The following table shows the programming operations of the dip-switch inside the transmitter and the BUS 2-EASY photocells receiver.



PHOTOCELLS BUS-2EASY

ADDRESSING THE BUS-2EASY PHOTOCELLS

Important: the same address must be given to both transmitter and receiver. Make sure that there are not two or more photocell pairs with the same address. If you are not using any BUS-2EASY accessory, leave free connector BUS-2EASY


| Dip1 | Dip2 | Dip3 | Dip4 | Rif.  | Type                |
|------|------|------|------|-------|---------------------|
| OFF  | OFF  | OFF  | OFF  | B - C | OPENING             |
| OFF  | OFF  | OFF  | ON   |       |                     |
| OFF  | OFF  | ON   | OFF  |       |                     |
| OFF  | OFF  | ON   | ON   |       |                     |
| OFF  | ON   | ON   | OFF  |       |                     |
| OFF  | ON   | ON   | ON   | D     | CLOSING             |
| ON   | OFF  | OFF  | OFF  |       |                     |
| ON   | OFF  | OFF  | ON   |       |                     |
| ON   | OFF  | ON   | OFF  |       |                     |
| ON   | OFF  | ON   | ON   |       |                     |
| ON   | ON   | OFF  | OFF  | A     | OPENING and CLOSING |
| ON   | ON   | OFF  | ON   |       |                     |
| ON   | ON   | ON   | OFF  |       |                     |
| OFF  | ON   | OFF  | OFF  |       |                     |
| OFF  | ON   | OFF  | ON   |       |                     |
| ON   | ON   | ON   | ON   | /     | OPEN PULSE          |

**ADDRESSING THE BUS-2EASY ENCODERS**

Connection of the BUS-2EASY input in the control board is via the bipolar cables which come out of the encoders.

**⚠** Unlike the case of the photocell devices, the polarity of the BUS-2EASY line connection determines whether the encoder belongs to one leaf rather than to the other.


**ENCODER WIRING FOR OPERATOR S700H/S800H**



**⚡** \* LEAF 1 OPENS AS FIRST AND CLOSES AS SECOND. IF NO REBATE IS PRESENT BETWEEN LEAF 1 AND 2, SET LEAF DELAY TO ZERO ON THE CONTROL BOARD.

**⚡** REVERSE THE ENCODER WIRES TO EXCHANGE BETWEEN THE ENCODER ASSOCIATED WITH LEAF 1 AND THE ENCODER ASSOCIATED WITH LEAF 2 AND VICE VERSA


**SAFECODER WIRING (Operators 412, 413, 415, 770N, S450H)**



**⚡** \* LEAF 1 OPENS AS FIRST AND CLOSES AS SECOND. IF THERE IS NO REBATE BETWEEN LEAF 1 AND 2, SET THE LEAF DELAY TO ZERO ON THE CONTROL BOARD.


**⚡** REVERSE THE ENCODER WIRES TO EXCHANGE BETWEEN THE ENCODER ASSOCIATED WITH LEAF 1 AND THE ENCODER ASSOCIATED WITH LEAF 2, AND VICE VERSA

**ENCODER WIRES REVERSING OPERATION**



ENGLISH

**Connector J13 – XF MODULE rapid connection**



The control unit has an integrated 2-channel decoding system (DS, SLH, LC/RC) named OMNIDEC. This system makes it possible to save – through an extra receiver module – XF433 or XF868 radio commands of the same frequency, but of a different type (DS, SLH, LC/RC). It is possible to save both total opening (OPEN A) and partial opening (OPEN B) of the automated system, up to a maximum of 256 channels.



**Insert and remove the boards only after cutting power.**

**PROGRAMMING**

Programming is divided in two levels:


- **BASIC programming**
- **ADVANCED programming**

The programming phases are (see **Tab.**):

1. to access PROGRAMMING (**1A** or **1B**);
2. to show the set values and modify them, if you want. *Changing the values is effective immediately, while the final memorisation must be carried out upon exiting programming (St).*
3. exit the programming by using St function. Select **Y** to SAVE the configuration you just performed, otherwise select **no** to EXIT WITHOUT SAVING any changes.

You can **EXIT programming at anytime**:

- press and hold **F** and then also **-** to switch directly to **St**.



This board also allows **programming using a PC or MAC**.

This programming requires connection to PC/MAC via USB cable and USB-B relevant port.

The programming SOFTWARE with relevant instructions, must be downloaded from the website:

[www.faacgroup.com](http://www.faacgroup.com)

The programming using a PC/MAC, with the **default PASSWORD** does not inhibit the programming by board. The writing **PC** will be displayed in correspondence with the modified values. **Notes**: when you modify the values by board the previous PC/MAC programming will be overwrote.

The default password is **0000**.

The programming using a PC/MAC, with a modified PASSWORD (different from the default one), will inhibit the programming by board. If one of the buttons is pressed, the display will show **PC** programming for 5 sec and changes will be allowed only by PC /MAC.

|                      | 1  |  | 2  |  | 3  |
|----------------------|--|--|--|--|--|
| BASIC PROGRAMMING    | <p><b>1A. PRESS AND HOLD F :</b><br/>THE FIRST FUNCTION APPEARS </p>                 | <p>RELEASE <b>F</b>:<br/>THE FUNCTION VALUE IS DISPLAYED</p> | <p>USING <b>+</b> OR <b>-</b>,<br/>SCROLL THE AVAILABLE VALUES UNTIL THE THE DESIRED ONE</p> | <p>PRESS <b>F</b>:<br/>TO MOVE TO THE NEXT FUNCTION </p> | <p>FUNCTION <b>St</b><br/>(LAST BASIC OR ADVANCED FUNCTION)</p>  |
| ADVANCED PROGRAMMING | <p><b>1B. PRESS AND HOLD F AND THEN ALSO + :</b><br/>THE FIRST FUNCTION APPEARS </p> | <p>RELEASE THE KEYS:<br/>THE FUNCTION VALUE IS DISPLAYED</p> | <p><b>+/R1 -/R2</b></p>  | <p>PRESS <b>F</b>:<br/>TO MOVE TO THE NEXT FUNCTION </p> | <p>SELECT <b>Y</b> TO SAVE THE PROGRAMMING<br/>OTHERWISE<br/>SELECT <b>no</b> TO EXIT THE PROGRAMMING WITHOUT SAVING</p> |

THE FUNCTION IS DISPLAYED UNTIL YOU HOLD

**Tab.** Programming phases.

**BASIC PROGRAMMING**

| Display   | Basic Function  | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|-----------|---|-----------|-----------|-----------|-----------|-----------|-----------|
| <b>CF</b> | <p><b>0</b> Configures the parameters with DEFAULT values corresponding to an installation with non-FAAC operators. (see default column 0).</p> <p><b>1</b> Configures the parameters with DEFAULT values corresponding to an installation with operators <b>FAAC 412, 413/415, 770, 390, 770N</b> (see default column 1).</p> <p><b>2</b> Configures the parameters with DEFAULT values corresponding to an installation with operators <b>FAAC 391</b> (see default column 2).</p> <p><b>3</b> Configures the parameters with DEFAULT values corresponding to an installation with operators <b>FAAC S700H/S800H</b> (see default column 3).</p> <p><b>4</b> Configures the parameters with DEFAULT values corresponding to an installation with operators <b>FAAC 418</b>. (see column default 4).</p> <p><b>5</b> Configures the parameters with DEFAULT values corresponding to an installation with operators <b>FAAC S450H</b> (see column default 5).</p> <p><b>PC</b> Mixed configuration from a PC/MAC</p> <p> <b>At the time of changing the set motor type on the board, the relevant defaults are uploaded.</b></p> | <b>0</b>  | <b>1</b>  | <b>2</b>  | <b>3</b>  | <b>4</b>  | <b>5</b>  |
| <b>DF</b> | <p><b>DEFAULT:</b></p> <p><b>y</b> indicates that all the set values correspond to the default values.</p> <p><b>no</b> indicates that one or more set values are different from the default.</p> <p>Set <b>y</b> if you want to restore the default settings.</p>  | <b>y</b>  | <b>y</b>  | <b>y</b>  | <b>y</b>  | <b>y</b>  | <b>y</b>  |
| <b>LO</b> | <p><b>FUNCTION LOGICS:</b></p> <p><b>E</b> Semi-automatic</p> <p><b>EP</b> Semi-automatic Step-by-Step</p> <p><b>S</b> Automatic Safety Devices</p> <p><b>SA</b> Automatic with reversal during pause</p> <p><b>SP</b> Automatic Step-by-Step Safety Devices</p> <p><b>AI</b> Automatic 1</p> <p><b>A</b> Automatic</p> <p><b>AP</b> Automatic Step-by-Step</p> <p><b>At</b> Automatic timer</p> <p><b>b</b> Semi-automatic "b"</p> <p><b>bC</b> Mixed (Pulses for opening / Dead-man commands for closing)</p> <p><b>C</b> Dead-man</p> <p><b>CU</b> Logic modified from a PC/MAC</p> <p> <b>Other more detailed programming possibilities are feasible by programming with a PC (see dedicated instructions).</b></p>  | <b>E</b>  | <b>E</b>  | <b>E</b>  | <b>E</b>  | <b>E</b>  | <b>E</b>  |

| Display | Basic Function   | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|--|-----------|-----------|-----------|-----------|-----------|-----------|
| PA      | <p><b>PAUSE TIME A (visualised only if the selected logic allows automatic reclosing):</b></p> <p>Pause time following a <b>TOTAL</b> opening command. It has only effect if a logic with pause time was selected. Can be adjusted from 0 to 59 sec. in one-second steps.</p> <p>Next, the viewing changes in minutes and ten seconds (separated by a dot) and time is adjusted in 10-second steps, up to the maximum value of <b>9.5</b> minutes.</p> <p><i>E.g.: if the display shows <b>2.5</b>, the pause time will be 2 min. and 50 sec.</i></p>  | 30        | 30        | 30        | 30        | 30        | 30        |
| Pb      | <p><b>PAUSE TIME B (visualised only if the selected logic allows automatic reclosing):</b></p> <p>Pause time following a <b>PARTIAL</b> opening command. It has only effect if a logic with pause time was selected.</p>   | 30        | 30        | 30        | 30        | 30        | 30        |
| Mn      | <p><b>NR. OF MOTORS:</b></p> <p>You can select the number of motors present in the system:</p> <p><b>1</b> = 1 motor<br/><b>2</b> = 2 motors</p> <p> <i>If the SETUP is performed with only one motor, and later two motors are used, the board will signal error <b>14</b> - configuration error, which can be deleted by repeating the SETUP with two motors or by returning to one motor.</i></p> <p><i>If a SETUP is performed with two motors and later only one is used, the board will not signal an error. Only the motor connected to input M1 will move.</i></p> <p><i>When programming from a PC/MAC, you can select different partial openings.</i></p> | 02        | 02        | 02        | 02        | 02        | 02        |
| F1      | <p><b>MOTOR 1 POWER :</b></p> <p>You can adjust the maximum power of motor 1, which is the same during both opening and closing.</p> <p><b>01</b> = minimum power<br/><b>50</b> = maximum power</p> <p> <i>If the power is modified, we recommend performing a new SETUP - see the related paragraph.</i></p> <p> <i>Other more detailed programming possibilities are feasible by programming with a PC (see dedicated instructions).</i></p>   | 25        | 25        | 25        | 40        | 25        | 35        |
| F2      | <p><b>MOTOR 2 POWER (visualised only with the function Mn = 2):</b></p> <p>You can adjust the maximum power of motor 2, which is the same during both opening and closing.</p>   | 25        | 25        | 25        | 40        | 25        | 35        |
| SP      | <p><b>SPEED:</b></p> <p>Adjusts the motion speed of the motors. There are 10 levels. The value is relative and not absolute, because the speed value refers to the weight of the leaf measured during the SETUP cycle</p> <p><b>01</b> = minimum speed<br/><b>10</b> = maximum speed</p> <p> <i>Other more detailed programming possibilities are feasible by programming with a PC (see dedicated instructions).</i></p>   | 08        | 08        | 08        | 08        | 08        | 08        |

| Display | Basic Function   | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|--|-----------|-----------|-----------|-----------|-----------|-----------|
| En      | <p><b>ENCODER USE:</b><br/>You can enable/disable the use of encoders (both BUS and GATECODER encoders):</p> <p>4 = encoders on both motors<br/>no = encoders disabled</p> <p> <i>When using configurations 3 or 5 it is mandatory to use the encoder. no is not selectable</i></p>   | no        | no        | no        | 4         | no        | 4         |
| FA      | <p><b>LIMIT SWITCH WHEN OPENING:</b><br/>Lets you set or disable use of the opening limit switch on swing-leaves .</p> <p>no = opening limit switches disabled<br/>01 = the limit switch determines the stopping of motion<br/>02 = the limit switch determines the start of deceleration</p> <p> <i>After having changed the value of this function, SETUP is required: the card will signal error 14 (configuration error) until the SETUP is performed again or until the previous value is restored</i></p>   | no        | no        | no        | no        | no        | no        |
| FC      | <p><b>LIMIT SWITCH WHEN CLOSING:</b><br/>Lets you set or disable use of the closing limit switch on swing-leaves.</p> <p>no = closing limit switches disabled<br/>01 = the limit switch determines the stopping of motion<br/>02 = the limit switch determines the start of deceleration</p> <p> <i>After having changed the value of this function, SETUP is required: the card will signal error 14 (configuration error) until the SETUP is performed again or until the previous value is restored.</i></p> | no        | no        | no        | no        | no        | no        |
| cd      | <p><b>DELAY FOR CLOSING LEAF (visualised only with the function Mn = 2):</b><br/>Is the delay time for starting leaf 1 closing with respect to leaf 2. Makes it possible to avoid overlapping of the two leaves. Adjustable from 00 to 59 sec, in 1- second steps. Next the value 59, the viewing changes to minutes and tenths of a second (separated by a decimal point) and time is adjusted in 10-second steps up to the maximum value of 3 minutes.</p> <p><i>e.g.: if the display shows 1.2, the time is 1 min and 20 sec</i></p>  | 05        | 05        | 05        | 05        | 05        | 05        |
| bu      | <p><b>BUS-2EASY DEVICES ENTRY:</b><br/>See the related paragraph.</p>  | no        | no        | no        | no        | no        | no        |
| M2      | <p><b>MOTOR 2 dead-man DRIVE mode (visualised only with the function Mn = 2)</b></p> <p>+/R1  OPENS (visualising oP) until the button is held down</p> <p>-/R2  CLOSES (visualising cL) until the button is held down</p>  | --        | --        | --        | --        | --        | --        |

| Display | Basic Function  | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|---|-----------|-----------|-----------|-----------|-----------|-----------|
| M1      | <b>MOTOR 1 dead-man DRIVE mode</b><br>+/R1  OPENS (visualising oP) until the button is held down<br>-/R2  CLOSES (visualising cL) until the button is held down   | --        | --        | --        | --        | --        | --        |
| tL      | <b>WORK TIME LEARNING (SETUP):</b><br>See the related paragraph.  | --        | --        | --        | --        | --        | --        |
| St      | <b>AUTOMATED SYSTEM STATUS:</b><br>You can exit programming, choosing whether or not to save the configuration you just performed.<br><br>1. set the choice:<br>y to SAVE and EXIT the programming<br>no to EXIT the programming WITHOUT SAVING<br><br>2. press the button F to confirm; at the end the display returns to visualize the <b>automated system status</b> :<br>00 = CLOSED<br>01 = OPEN<br>02 = Stationary then "OPENS"<br>03 = Stationary then "CLOSES"<br>04 = In "PAUSE"<br>05 = during Opening<br>06 = during Closing<br>07 = FAIL SAFE in progress<br>08 = checking BUS-2EASY devices in progress<br>09 = Pre-flash then "OPENS"<br>10 = Pre-flash then "CLOSES"<br>11 = Emergency open<br>12 = Emergency close<br>HP = Hold position<br><br> <b>WARNING</b> If power is lost to the board prior to confirmation (step 2.), all changes made will be lost.<br><br>You can EXIT programming at any time: press and hold F and then also = to switch directly to St.<br><br><br>-/R2 F | y         |           |           |           |           |           |

## ADVANCED PROGRAMMING

| Display | Advanced Function  | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|--|-----------|-----------|-----------|-----------|-----------|-----------|
| bo      | <p><b>TIME OF MAXIMUM POWER AT STARTING:</b></p> <p>You can set the starting time. During start the motors work at maximum power for starting the movement. Adjustable from 00 to 10 sec, in 1-second steps (ignoring the power level selected with F1 and F2).</p> <p> Other more detailed programming possibilities are feasible by programming with a PC (see dedicated instructions).</p>   | 02        | 02        | 02        | 02        | 02        | 02        |
| cs      | <p><b>FINAL STROKE WHEN CLOSING (RAM STROKE) (NOT displayed if function FC = 1):</b></p> <p>Lets you enable/disable the ram stroke on swing-leaves.</p> <p>The ram stroke facilitates latching of the electric lock by activating the motors at maximum power during final closing.</p> <p>4 = enabled (for 2 sec)<br/>no = disabled</p> <p> In case of systems with an absolute encoder, to enable this function a setup must be performed using the automatic leaf stop on the mechanical contact point.</p>                          | no        | no        | no        | no        | no        | no        |
| rs      | <p><b>REVERSE STROKE WHEN OPENING displayed if function FA = 1):</b></p> <p>Lets you enable/disable the reverse stroke on leaf doors. The reverse stroke facilitates unlatching of the electric lock. When the automatic system is closed, before starting to open, the motors give a brief push to close.</p> <p>4 = enabled (for 2 sec)<br/>no = disabled</p> <p> In case of systems with an absolute encoder, to enable this function a setup must be performed using the automatic leaf stop on the mechanical contact point.</p> | no        | no        | no        | no        | no        | no        |
| EL      | <p><b>ELECTRIC LOCK ON LEAF 2:</b></p> <p>The board has a terminal dedicated to the connection of an electric lock. Normally the electric lock must be connected to leaf 1. If the electric lock is located on leaf 2, adjust the parameter. This parameter does not allow the setting 4 if Fn = 2)</p> <p>4 = electric lock on leaf 2<br/>no = electric lock on leaf 1</p>  | no        | no        | no        | no        | no        | no        |
| Od      | <p><b>DELAY FOR OPENING LEAF (visualised only with the function Fn = 2):</b></p> <p>You can set the delay time for starting leaf 2 opening with respect to leaf 1, in order to avoid overlapping of the two leaves. Adjustable from 00 to 59 sec, in 1- second steps. Next the value 59, the viewing changes to minutes and tenths of a second (separated by a decimal point) and time is adjusted in 10-second steps up to the maximum value of 1.3 minutes. e.g.: if the display shows 1.2, the time is 1 min and 20 sec.</p>  | 02        | 02        | 02        | 02        | 02        | 02        |

| Display | Advanced Function  | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|--|-----------|-----------|-----------|-----------|-----------|-----------|
| r1      | <p><b>LEAF 1 DECELERATION:</b></p> <p>You can adjust the deceleration space as a percentage of the total travel of leaf 1.<br/>Adjustable from 00 to 99 %, in 1% steps.</p> <p>00 = no deceleration<br/>01 = minimum deceleration space<br/>99 = maximum deceleration space</p>  | 30        | 30        | 30        | 20        | 30        | 30        |
| r2      | <p><b>LEAF 2 DECELERATION (visualised only with the function <math>r_n = 2</math>):</b></p> <p>You can adjust the deceleration space as a percentage of the total travel of leaf 2.<br/>Adjustable from 00 to 99 %, in 1% steps.</p> <p>00 = no deceleration<br/>01 = minimum deceleration space<br/>99 = maximum deceleration space</p>   | 30        | 30        | 30        | 20        | 30        | 30        |
| PF      | <p><b>PRE-FLASHING:</b></p> <p>You can enable/disable the pre-flashing. Pre-flashing duration = 3 sec.</p> <p>You can choose:</p> <p>no = disabled<br/>0C = pre-flashing before each movement<br/>CL = pre-flashing before a closing movement<br/>0P = pre-flashing before an opening movement<br/>PA = pre-flashing only at the end of the pause time</p>   | no        | no        | no        | no        | no        | no        |
| Ph      | <p><b>CLOSING PHOTOCELLS:</b></p> <p>The intervention of closing photocells causes the reversing of automated system (opening).<br/>You can choose:</p> <p>y = operate the reversal only after the photocells are released<br/>no = operate the reversal immediately</p>   | no        | no        | no        | no        | no        | no        |
| Ad      | <p><b>ADMAP FUNCTION:</b></p> <p>Allows operation in compliance with French regulation NFP 25/362.</p> <p>y = enabled<br/>no = disabled</p>  | no        | no        | no        | no        | no        | no        |
| EC      | <p><b>ANTI-CRUSHING SENSITIVITY:</b></p> <p>Varying this function varies the amount of time after which, in case of obstacle, the board commands reversal of the leaves, or it will command a stop if the leaves are in the contact point search space (see the parameter r8).</p> <p>The fourth consecutive obstacle detected in the same direction and position will be defined as a contact point and the leaf will stop in that position.</p> <p>01 = minimum sensitivity (maximum time before reversal)<br/>10 = maximum sensitivity (minimum time before reversal)</p> | 01        | 06        | 06        | 05        | 06        | 05        |
| US      | <p><b>ULTRA-SENSITIVITY:</b></p> <p>This function activates an obstacle detection system, based on the control of the variation of the current absorbed by the motor, causing immediate leaf reversal.</p> <p>y = active<br/>no = excluded</p>   | no        | no        | no        | y         | no        | y         |

| Display | Advanced Function   | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|---|-----------|-----------|-----------|-----------|-----------|-----------|
| 78      | <p><b>MECHANICAL STOP SEARCH ANGLE (NOT displayed if function FC or FA = 01):</b></p> <p>You can adjust the contact point search angle within which the board will stop movement without reversing, if it encounters an obstacle or the contact point.</p> <p>Adjustable from 0.3 to 20 degrees.</p> <p>From 0.3 to 9.9 degrees, adjustments are made in 0.1 degree steps.</p> <p>From 10 to 20 degrees, adjustments are made in 1 degree steps.</p>  | 10        | 10        | 10        | 4.0       | 10        | 4.0       |
| 5F      | <p><b>SOFT TOUCH: (visualised only with the function En = no):</b></p> <p>After touching the travel stop point, the leaves reverse and then rest gently.</p> <p>Y = active<br/>no = excluded</p> <p> This function can be useful to respect the impact curve specified by current standards.</p> <p> Other more detailed programming possibilities are feasible by PC programming (see dedicated instructions).</p>   | no        | no        | no        | no        | no        | no        |
| 01      | <p><b>OUT 1:</b></p> <p>You can set the output OUT1 (open collector N.O.) in one of the following functions:</p> <p>00 = always active</p> <p>01 = FAIL-SAFE</p> <p>02 = INDICATOR LIGHT (off = closed; on = during opening and open/in pause; flashing = during closing)</p> <p>03 = COURTESY LIGHT (stays on for the duration of the movement (even in SETUP) in addition to the set time of function t1)</p> <p>04 = ACTIVE ERROR</p> <p>05 = automated system OPEN or in PAUSE</p> <p>06 = automated system CLOSED</p> <p>07 = automated system MOVING</p> <p>08 = automated system in EMERGENCY</p> <p>09 = automated system in OPENING</p> <p>10 = automated system in CLOSING</p> <p>11 = electric lock control before CLOSING</p> <p>12 = safety device ACTIVE</p> <p>13 = TRAFFIC LIGHT function (active when OPENING and with automated system OPEN)</p> <p>14 = timed output which can be activated from the second radio channel OMNIDEC (see function t1)</p> <p>15 = output which can be activated from the second radio channel OMNIDEC (step-by-step function)</p> <p>16 = active during movement of leaf 1</p> <p>17 = active during movement of leaf 2</p> <p>18 = Intrusion detection</p> <p>19 = System working on battery</p> <p> If tr is displayed, it indicates that the output is used as a TIMER set from the PC/MAC software.</p> | 00        | 00        | 00        | 00        | 00        | 00        |

| Display | Advanced Function  | Default 0 | Default 1 | Default 2 | Default 3 | Default 4 | Default 5 |
|---------|--|-----------|-----------|-----------|-----------|-----------|-----------|
| t1      | <b>OUT 1 TIMING (visualised only with the function o1 = 03 or o1 = 14):</b><br>You can adjust the timing of OUT 1 output if a timed function has been selected with a time from 1 to 59 minutes in 1-minute steps for functions 03-14  | 01        | 01        | 01        | 01        | 01        | 01        |
| o2      | <b>OUT 2:</b><br>You can set the output OUT2 (open collector N.O.).<br>See the options as o1.  | 02        | 02        | 02        | 02        | 02        | 02        |
| t2      | <b>OUT 2 TIMING (visualised only with the function o2 = 03 or o2 = 14):</b><br>Adjustable as t1.   | 01        | 01        | 01        | 01        | 01        | 01        |
| AS      | <b>MAINTENANCE REQUEST - CYCLE COUNTER (linked to the subsequent two functions):</b><br>You can enable the signaling of maintenance request, or the cycle counter.<br><b>y</b> = enable the SIGNALING when the programmed number of cycles has been reached (as defined in subsequent two functions nc and nd).<br>Signaling consists of a pre-flashing of 8 sec (in addition to the time may already be set with the function PF) before each movement.<br><b>no</b> = enable the CYCLE COUNTER, that will be displayed in the subsequent two functions nc and nd up to a displayed maximum of 65,530.<br> If the number of cycles performed is greater than 65,530 the subsequent two functions nc and nd will display 65 and 53, respectively. | no        | no        | no        | no        | no        | no        |
| nc      | <b>CYCLE PROGRAMMING (THOUSANDS):</b><br>If AS = y the display will show the number of thousands of cycles after which the signaling of maintenance request begins (can be set from 0 to 99).<br>If AS = no the display will show the number of thousands of work cycles performed. The value displayed is updated with the succession of the cycles, interacting with the value in nd.<br> When AS = no you can reset the cycle counter: press simultaneously + and - for 5 sec.   | 00        | 00        | 00        | 00        | 00        | 00        |
| nd      | <b>CYCLE PROGRAMMING (TENS):</b><br>If AS = y the display will show the number of tens of cycles after which the signaling of maintenance request begins (can be set from 0 to 99).<br>If AS = no the display will show the number of tens of work cycles performed. The value displayed is updated with the succession of the cycles, interacting with the value in nc.<br> e.g.: if the system has performed 11,218 cycles, nc = 11 and nd = 21 will be displayed   | 00        | 00        | 00        | 00        | 00        | 00        |

St

**AUTOMATED SYSTEM STATUS:**

You can exit programming, choosing whether or not to save the configuration you just performed.

1. set the choice:

**4** to SAVE and EXIT the programming

**no** to EXIT the programming WITHOUT SAVING

2. press the button **F** to confirm; at the end the display returns to visualize the **automated system status**:

**00** = CLOSED

**01** = OPEN

**02** = Stationary then "OPENS"

**03** = Stationary then "CLOSES"

**04** = In "PAUSE"

**05** = Opening

**06** = Closing

**07** = FAIL SAFE in progress

**08** = checking BUS-2EASY devices in progress

**09** = Pre-flash then "OPENS"

**10** = Pre-flash then "CLOSES"

**11** = Emergency open

**12** = Emergency close

**HP** = Hold position

4

**BUS 2EASY DEVICE INSTALLATION**


You can add BUS-2EASY devices to the system at any time, proceeding as follows:

1. Cut off the electrical power to the board.
2. Install and set the BUS-2EASY accessories according to the instructions of the devices.
3. Connect the BUS-2EASY devices according to the instructions of Chapter **ELECTRICAL CONNECTIONS**.
4. Power up the board.
5. Complete the procedure for BUS-2EASY device entry.

**BUS-2EASY DEVICE ENTRY**

1. Access BASIC programming and scroll through the functions up until **bu**. When **F** is released, the display will show the BUS-2EASY devices status (see the figure).
2. Perform the entry: simultaneously press and hold **+** and **-** for at least 5 sec (during this time, the display will blink).
3. **4** will appear as a confirmation of entry completion.
4. Release the **+** and **-** buttons. The status of the BUS-2EASY devices will be displayed.


 If no BUS device has ever been entered in the board, the display will read **no**.




**Fig.** Visualising the BUS-2EASY status in the function **bu**: each segment of the display shows one type of device.

Fig. examples of BUS-2EASY status visualization on display.

In STAND BY (gate closed and in stand-by) with BUS-2EASY **Encoder** on leaf 1 and leaf 2 and BUS-2EASY **Photocells** correctly connected and entered.



In case of BUS-2EASY **Encoder** on leaf1 and leaf 2 and BUS-2EASY **Photocells** correctly connected and entered and with closing photocells engaged:




ENGLISH

**CHECKING THE SECURING DEVICES ENTERED ON THE BOARD**

To verify the types of BUS device recognised through the entry:

1. Press and hold the **+** button during stand-by visualisation; the segments corresponding to at least one entered device will go ON. E.g.:



To check the condition of the BUS-2EASY connection, verify the LED on the board:

**LED DL15 (Red)**

|            |   |
|------------|---|
| <b>ON</b>  | Safety device engaged or pulse generator active         |
| <b>OFF</b> | NO safety device engaged neither pulse generator active |

**LED DL14 (Green)**

|   |   |
|---|---|
| <b>ON steady</b>                            | Normal activity (led ON even if there are no devices).  |
| <b>Slow blinking (blink every 2,5 sec)</b>  | BUS-2EASY line short-circuit.   |
| <b>Rapid blinking (blink every 0.5 sec)</b> | Error in the BUS-2EASY connection.<br>Repeat the device entry. If the error occurs again, check:<br>- That there are no more than one device in the system with the same address.<br>- Calling error (number > or < the connected BUS devices).<br>- FAIL SAFE error on the BUS device. |
| <b>OFF</b>                                  | Board in Sleep mode (if used).  |

**TIME LEARNING - SETUP**

When the board is powered, if a SETUP has never been performed, or if the board requests it, on the display **50** indicates that a SETUP must be performed.

*During SETUP, the connected BUS-2EASY accessories are always entered. The BUS-2EASY encoders entered by the SETUP must always be enabled using the parameter **En** (BASIC Programming).*

**During SETUP all safety devices are disabled! Therefore, carry out the operation avoiding any transit in the leaf movement area.**

*If a system without an encoder is installed, mechanical stops will be required for the leaves.*

Perform the SET-UP as follows:

1. Enter BASIC programming and go to the parameter **L**, when F is released **--** will appear.
2. Ensure that the gate leaves are closed. Otherwise, proceed as follows:
  - Press and hold **-R2** to close leaf 2
  - Press and hold **+R1** to close leaf 1

 *Should pressing **+R1** and/or **-R2** command opening of the corresponding leaf, cut off power and, on terminal board J11 or J12, invert the cables of the corresponding motor.*

3. With the gate leaves closed, launch SETUP by pressing and holding **+** and **-** until **S1** begins to flash on the display (about 3 sec).
4. Release **+** e **-**. Leaf 1 begins its opening movement.

#### Operation WITHOUT Safecoder

Leaf 1 automatically acknowledges the mechanical stop.

#### Operation WITH Safecoder

Leaf 1 automatically acknowledges the mechanical stop. It will in any case be possible to stop leaf movement at any time and in the desired point by sending an OPEN A pulse.

5. On the display **S2** will flash (only if 2 motors have been selected): leaf 2 begins opening.

#### Operation WITHOUT Safecoder

Leaf 2 automatically acknowledges the mechanical stop.

#### Operation WITH Safecoder

Leaf 2 automatically acknowledges the mechanical stop. It will in any case be possible to stop leaf movement at any time and in the desired point by sending an OPEN A pulse.

#### Steps 4 and 5 with function **FA** :

**FA = 01** (the limit switch determines the stopping of motion) with **Safecoder** installed the OPEN A pulse for stopping motion is ignored.

**FA = 02** (the limit switch determines the start of deceleration) send an OPEN A pulse only after involving the opening limit switch, without **Safecoder**, make sure that the limit switch is engaged before the mechanical stop.

6. On the display **S3** will flash (only if 2 motors have been selected): leaf 2 begins closing.

#### Operation WITHOUT Safecoder

Leaf 2 automatically acknowledges the mechanical stop.

#### Operation WITH Safecoder

Leaf 2 automatically acknowledges the mechanical stop. It will in any case be possible to stop leaf movement at any time and in the desired point by sending an OPEN A pulse.

7. On the display **S4** flashes: leaf 1 begins closing.

#### Operation WITHOUT Safecoder

Leaf 1 automatically acknowledges the mechanical stop

#### Operation WITH Safecoder

Leaf 1 automatically acknowledges the mechanical stop. It will in any case be possible to stop leaf movement at any time and in the desired point by sending an OPEN A pulse.

#### Steps 6 and 7 with function **FC** :

**FC = 01** (the limit switch determines the stopping of motion) the OPEN A pulse for stopping motion is ignored.

**FC = 02** (the limit switch determines the start of deceleration) with **Safecoder** installed send an OPEN A pulse only after involving the closing limit switch, without **Safecoder**, make sure that the limit switch is engaged before the mechanical stop

8. **S5** flashes on the display: both leaves open at full speed.

9. The board will automatically exit the programming menu and will display the automated system status (**00**) to confirm that the SETUP procedure has been completed correctly. If the procedure is not completed correctly, on the display **S0** will start flashing, indicating that a new SETUP procedure must be performed.

 *The deceleration spaces can be configured and modified from the display using the parameters **r1** and **r2** (see Advanced Programming) without repeating the SETUP.*

### TESTING THE AUTOMATED SYSTEM

Once installation and programming is completed, ensure that the system is operating correctly.

Be especially careful that the safety devices operate correctly and ensure that the system complies with all current safety regulations. Close the cover in the provided seat with gasket.



## MEMORISING THE RADIO CODE

The control board features an integrated 2-channel decoding system (DS, SLH/SLH LR, RC) called OMNIDEC. This system lets you memorise, using an additional receiver module (on J5 connector) and more radio controls having different technology but the same frequency. You can thus control both total opening (OPEN A) and partial opening (OPEN B).

 The different types of radio code (DS, SLH/SLH LR, LC/RC) can coexist simultaneously on the two channels. You can enter up to 250 radio codes divided between OPEN A and OPEN B/CLOSE.


To use different encoding systems on the same channel, you must complete the learning of each encoding system and then repeat the procedure for the other one.

Other, more detailed, programming options are available using a PC/MAC (see dedicated PC/MAC instructions). For example, you can set an automatic OPEN command on the radio channel to command an automatic cycle (open-pause-close) regardless of the selected logic.

## MEMORISING THE SLH/SLH LR RADIO CONTROLS

1. Press and hold +/R1 - SW1 (OPEN A programming) or -/R2 - SW2 (OPEN B/CLOSE programming).
2. After keeping the button pressed for about 5 sec, the corresponding radio LED (DL11 or DL12) will begin to flash slowly for about 20 sec.
3. Release the button.
4. Simultaneously press and hold P1 and P2 on the SLH/SLH LR radio control (only MASTER radio control).
5. The radio control LED will begin to flash.
6. Release both buttons.
7. Ensure that LED DL11 or DL12 on the board is still flashing (see point 2) and, while the radio control LED is still flashing, press and hold the desired button on the radio control (the radio control LED will go on steady).
8. The corresponding LED on the board (DL11 or DL12) will go on steady for 1 sec and then go off, indicating that memorisation has been completed.
9. Release the radio control button.
10. To complete memorisation, press the button of the memorised radio control twice in succession. The automated system will perform an opening cycle.


 Ensure that there are no obstacles (by people or things) during the automated system movement.



To enable other radio controls with the same system code, you must transfer the system code of the memorised radio control button to the button corresponding to the radio control you wish to add:

1. Simultaneously press and hold P1 and P2 on the memorised radio control.
2. The radio control LED will begin to flash.
3. Release both buttons.
4. Press and hold, while the radio control LED is still flashing, the memorised button (the radio control LED will go on steady).
5. Bring the radio controls close together, press and hold the corresponding button of the radio control you wish to add, and release only after the radio control LED flashes twice, indicating that memorisation has been completed.
6. Press the button of the memorised radio control twice in succession. The automated system will perform an opening cycle.

**⚠ Ensure that there are no obstacles (by people or things) during the automated system movement.**




**MEMORISING LC/RC RADIO CONTROLS (433MHz ONLY)**

1. Press and hold +/R1 - SW1 (OPEN A programming) or -/R2 - SW2 (OPEN B/CLOSE programming).
2. After keeping the button pressed for about 5 sec, the corresponding radio LED (DL11 or DL12) will begin to flash slowly for about 20 sec.
3. Release the button.
4. During radio LED flashing, press the desired button of the LC/RC radio control.
5. The corresponding LED on the board (DL11 or DL12) will go on steady for 1 second, indicating that memorisation has been completed, and will begin flashing again for another 20 sec during which you can memorise another radio control.
6. When the 20 sec have elapsed, the LED will turn off, indicating that the procedure has been completed.
7. To add other radio controls, repeat the procedure from point

**REMOTE MEMORISATION OF LC/RC RADIO CONTROLS**

With LC/RC radio controls you can remotely memorise other radio controls, i.e. without working directly on the board, using a previously memorised radio control.


1. Take a radio control that has already been memorised on one of the 2 channels (OPEN A or OPEN B/CLOSE) and move to the vicinity of the board.
2. Simultaneously press and hold P1 and P2 until both LEDs flash slowly for 5 sec.
3. Within 5 seconds, press the previously memorised radio control button to activate the learning phase for the selected channel.
4. The LED on the board corresponding to the channel in learning mode will flash for 20 sec within which another radio control code is transmitted by pressing the button.
5. The corresponding LED on the board will go on steady for 2 sec (indicating that memorisation has been completed) and will begin flashing again for another 20 sec, during which you can memorise other radio controls, and will finally go off.



**MEMORISING DS RADIO CONTROLS**

1. On the DS radio control, choose the desired ON - OFF combination of the 12 dip-switches.
2. Press and hold +/R1 - SW1 (OPEN A programming) or -/R2 - SW2 (OPEN B/CLOSE programming).
3. After keeping the button pressed for about 5 sec, the corresponding radio LED (DL11 or DL12) will begin to flash slowly for about 20 sec.
4. Release the button.
5. During radio LED flashing, press the button of the radio control you wish to program.
6. The corresponding LED on the board (DL11 or DL12) will go on steady for 1 second and then go off, indicating that memorisation has been completed.
7. To add other different codes, repeat the procedure starting from point 1.
8. To add other radio controls with the same code, set the 12 dip-switches according to the same combination as the already memorised radio control.

ENGLISH



**DELETING THE RADIO CONTROLS**

**⚠ This operation CANNOT be reversed. This will delete ALL the radio control codes memorised as both OPEN A and OPEN B/ CLOSE. The cancellation procedure is active only in gate status visualisation mode.**

1. Press and hold -/R2 .
2. After pressing for about 5 sec, the DL12 LED begins to flash slowly; after another 5 sec of slow flashing and holding, the LEDs DL11 and DL12 begin flashing more rapidly (cancellation has started).
3. Once rapid flashing has stopped, LEDs DL11 and DL12 will go on steady, confirming the cancellation of all the radio codes (OPEN A and OPEN B/CLOSE) from the board memory.
4. Release -/R2 . The LEDs will go off, indicating correct cancellation.

## SIGNALLING ERRORS AND ALARMS

In case of **ERRORS** (conditions that stop gate operation) or **ALARMS** (conditions that do not compromise gate operation) the display will show the number corresponding to the warning in progress by simultaneously pressing **+** and **-**.

 These warnings will disappear in the following cycle only if the situation causing them is removed.

### Errors

 When there is an **ERROR** the **ERROR LED** will go on steady. By simultaneously pressing **+** and **-** the display will show the corresponding error number.

The following table contains all the errors that can be viewed on the display.

| N° | ERROR                          | SOLUTION  |
|----|--------------------------------|---|
| 01 | Board broken                   | Replace the board   |
| 05 | Invalid SETUP                  | Repeat board SETUP  |
| 08 | BUS-2EASY device error         | Ensure that no two pairs of devices have the same address.  |
| 09 | BUS-2EASY output short-circuit | Check the connections of the connected and entered BUS-2EASY devices  |
| 10 | Motor 1 limit switch error     | Check the limit switch connections for motor 1  |
| 11 | Motor 2 limit switch error     | Check the limit switch connections for motor 2  |
| 12 | BUS-2EASY call                 | Ensure that the BUS devices are operating correctly and, if necessary, repeat BUS device acquisition          |
| 13 | FAIL SAFE                      | Check that the safety devices (photocells) are operating correctly  |
| 14 | Configuration error            | Check that the board is configured correctly (basic and advanced programming) and, if necessary, repeat SETUP |
| 17 | Motor 1 encoder fault          | Check the connections or replace motor 1 encoder  |
| 18 | Motor 2 encoder fault          | Check the connections or replace motor 2 encoder  |
| 19 | Incorrect memory data          | Repeat BUS-2EASY device entry and/or re-program the board   |
| 93 | High absorption at +24V        | Check that absorption by the accessories connected is within permitted limits                                 |

### Alarms

 When there is an **ALARM** the **ERROR LED** will begin to flash. By simultaneously pressing **+** and **-** the display will show the corresponding alarm number.

The following table contains all the alarms that can be viewed on the display.

| N° | ALARM   | Solution/Description  |
|----|---|---|
| 20 | Obstacle on MOTOR 1 (only with encoder)                             | Remove any possible obstacle on leaf 1  |
| 21 | Obstacle on MOTOR 2 (only with encoder)                             | Remove any possible obstacle on leaf 2  |
| 25 | LOCK 1 output short-circuit   | Remove the cause of the short-circuit   |
| 26 | LOCK 2 output short-circuit   | Remove the cause of the short-circuit   |
| 27 | Nr. of consecutive obstacles exceeded during opening                | Remove any possible obstacle.<br>Should the problem persist, repeat SETUP                                       |
| 28 | Nr. of consecutive obstacles exceeded during closing                | Remove any possible obstacle.<br>Should the problem persist, repeat SETUP                                       |
| 30 | XF radio code memory full   | Cancel the radio codes that are not being used using the PC program or use an additional DEC/MI-NIDEC/RP module |
| 31 | Tampering alarm   | Movement was performed with automation in status <b>St=00</b> or <b>01</b> . Perform a manoeuvre cycle.         |
| 35 | TIMER active and TIMER function operating:                          | TIMER function is operating   |
| 40 | Service request   | Contact the installer for maintenance   |
| 50 | The HOLD POSITION is operating (active on PC/MAC)                   | HOLD POSITION function is operating   |
| 60 | TIMER active and error in TIMER data                                | Reload a correct TIMER configuration with the PC/MAC programme  |
| 62 | Loss of time and date on the board (only if the TIMER is operating) | Reload the time and date with the PC/MAC programme and replace the BAT1 - CR2032 buffer battery                 |
| 63 | JOLLY TIMER is activated  | JOLLY TIMER is enabled by terminal board J3   |
| 64 | TIMER DISABLED is operating   | TIMER is disabled by terminal board J3  |

## SEDE - HEADQUARTERS

### FAAC S.p.A.

Via Calari, 10  
40069 Zola Predosa (BO) - ITALY  
Tel. +39 051 61724 - Fax +39 051 758518  
www.faac.it - www.faacgroup.com

## ASSISTENZA IN ITALIA

### SEDE

tel. +39 051 6172501  
www.faac.it/ita/assistenza

### FIRENZE

tel. +39 055 301194  
filiale.firenze@faacgroup.com

### MILANO

tel +39 02 66011163  
filiale.milano@faacgroup.com

### PADOVA

tel +39 049 8700541  
filiale.padova@faacgroup.com

### ROMA

tel +39 06 41206137  
filiale.roma@faacgroup.com

### TORINO

tel +39 011 6813997  
filiale.torino@faacgroup.com

## SUBSIDIARIES

### AUSTRIA

FAAC GMBH  
Salzburg - Austria  
tel. +43 662 8533950  
www.faac.at

FAAC TUBULAR MOTORS  
tel. +49 30 56796645  
faactm.info@faacgroup.com  
www.faac.at

### AUSTRALIA

FAAC AUSTRALIA PTY LTD  
Homebush, Sydney - Australia  
tel. +61 2 87565644  
www.faac.com.au

### BENELUX

FAAC BENELUX NV/SA  
Brugge - Belgium  
tel. +32 50 320202  
www.faacbenelux.com

FAAC TUBULAR MOTORS  
tel. +31 475 406014  
faactm.info@faacgroup.com  
www.faacbenelux.com

### CHINA

FAAC SHANGHAI  
Shanghai - China  
tel. +86 21 68182970  
www.faacgroup.cn

### FRANCE

FAAC FRANCE  
Saint Priest, Lyon - France  
tel. +33 4 72218700  
www.faac.fr

FAAC FRANCE - AGENCE PARIS  
Massy, Paris - France  
tel. +33 1 69191620  
www.faac.fr

FAAC FRANCE - DEPARTEMENT  
VOLETS  
Saint Denis de Pile - Bordeaux - France  
tel. +33 5 57551890  
www.faac.fr

### GERMANY

FAAC GMBH  
Freilassing - Germany  
tel. +49 8654 49810  
www.faac.de

FAAC TUBULAR MOTORS  
tel. +49 30 5679 6645  
faactm.info@faacgroup.com  
www.faac.de

### INDIA

FAAC INDIA PVT. LTD  
Noida, Delhi - India  
tel. +91 120 3934100/4199  
www.faacindia.com

### IRELAND

NATIONAL AUTOMATION LIMITED  
Boyle, Co. Roscommon - Ireland  
tel. +353 071 9663893  
www.faac.ie

### MIDDLE EAST

FAAC MIDDLE EAST FZE  
Dubai Silicon Oasis free zone  
tel. +971 4 372 4187  
www.faac.ae

### NORDIC REGIONS

FAAC NORDIC AB  
Perstorp - Sweden  
tel. +46 435 779500  
www.faac.se

### POLAND

FAAC POLSKA SP.ZO.O  
Warszawa - Poland  
tel. +48 22 8141422  
www.faac.pl

### RUSSIA

FAAC RUSSIA LLC  
Moscow - Russia  
tel. +7 495 646 24 29  
www.faac.ru

### SPAIN

CLEM, S.A.U.  
S. S. de los Reyes, Madrid - Spain  
tel. +34 091 358 1110  
www.faac.

### SWITZERLAND

FAAC AG  
Altdorf - Switzerland  
tel. +41 41 8713440  
www.faac.ch

### TURKEY

FAAC OTOMATİK GEÇİŞ SİSTEMLERİ  
SAN. VE TIC. LTD. ŞTİ.  
Çağlayan, Kağıthane, İstanbul - Turkey  
tel. +90 (0)212 – 3431311  
www.faac.com.tr

### UNITED KINGDOM

FAAC UK LTD.  
Basingstoke, Hampshire - UK  
tel. +44 1256 318100  
www.faac.co.uk

### U.S.A.

FAAC INTERNATIONAL INC  
Rockledge, Florida - U.S.A.  
tel. +1 904 4488952  
www.faacusa.com

FAAC INTERNATIONAL INC  
Fullerton, California - U.S.A.  
tel. +1 714 446 9800  
www.faacusa.com

