



Be ahead



BEBA Wi-Fi




Wi-Fi expansion card for U-Link BFT products that allows the user and the installer to remotely control (via Wi-Fi, 4G connection or TCP/IP) the gate motor from smartphones and laptops.


If non U-Link products and/or non BFT products are used, the Clonix U-Link with the Beba Wi-Fi is required.

CODE	NAME	DESCRIPTION
P111494	BEBA Wi-Fi GATEWAY	Wi-Fi expansion card for U-Link products.
D113808 00003	CLONIX UNI AC U-LINK 240V	240V external receiver with 3 outputs (2 with NO contact and 1 NO/NC programmable) and 3 U-Link Beba slots. It can store up to 2048 remotes and it is compatible with the U-Link protocol.

BEBA Wi-Fi WITH U-CONTROL MAIN FEATURES



- Open/Close the gate;
- Check the status of the gate (Open/Closed/Moving);
- Create temporary users (Max. 5) that can download and use the app on their smartphone to Open/Close the gate;
- Create scenarios in order to control more than one automation together (Example: Open All/Close All);
- On IOS it's possible to set a GPS in order to open automatically the gate when the user is within a certain range (programmable in the app);
- Store the installer's information inside the app so, in case of emergency, the user can contact him.



BFT Automation Sydney Branch
29 Bentley St, Wetherill Park, NSW 2164
T (+61 2) 9757 0677 - F (+61 2) 9725 4225
www.bftaustralia.com.au
info@bftaustralia.com.au








BFT Automation Melbourne Branch
Unit 18 191-195 Greens Road, Dandenong South 3175
T (+61 3) 9793 1070 - F (+61 3) 9793 2243
www.bftaustralia.com.au
info@bftaustralia.com.au

BEBA Wi-Fi WITH U-BASE2 MAIN FEATURES



- Open/Close/Stop the gate;
- Check the status of the gate (Open/Closed/Moving);
- Check the current absorption, the status of the inputs/outputs and the torque in real time;
- Check and program the Parameters and Logic settings;
- Manage the receiver (add, delete, substitute, disable and clone remotes);
- Store the installation's details in the software (customer's name, address, phone number etc.) as well as the receiver and all the settings programmed.

ACCESSORIES

	CODE	NAME	DESCRIPTION
	P111469	BEBA BLUETOOTH	Bluetooth expansion card for U-Link products. To be used with U-Base2 software in order to set and control the gate motor via Bluetooth.
	P111530	BEBA RS 485 GATEWAY	RS485 expansion card for U-Link products. To be used with U-Base2 software in order to set and control the gate motor via RS485 connection.
	P111468	BEBA RS 485 LINK	Expansion card for Master/Slave connection. It is also used for serial connections when a U-Link network has to be created.
	P111510	U-BASE2	Managing and programming software for BFT control boards and receivers. It requires Wi-Fi, TCP/IP, RS485 or Bluetooth connection.
	P111523	U-BASE2 ANDROID	Managing and programming software (Android compatible) for BFT control boards and receivers. It requires Wi-Fi or Bluetooth connection.
	P111529	U-PROG	Programmer for remote controls and receivers with the possibility of wired or Bluetooth connection.
	P111718	U-BASE2 CLOUD 10	Licence to save up to 10 U-Base2 sites on the Cloud.

